



Transmit



Receive



Decode




Control

ELDAT

Boundless Liberty with ELDAT Radio

Easywave

Product Range



worldwide radio solutions: Building automation | Factory automation | Security Technology | Automotive Technology

ELDAT GmbH · Im Gewerbepark 14 · 15711 Zeesen · Germany · fon + 49 (0) 3375 9037-0 · fax + 49 (0) 3375 9037-90 · info@eldat.de · www.eldat.de

<p>Mini Transmitter</p>  <p>RT20-5004E-01</p>	<p>Micro Transmitter</p>  <p>RT21-5001E-01</p>	<p>Mini Transmitter</p>  <p>RT30-5004E-01</p>	<p>Mini Transmitter</p>  <p>RT30-5004E-01</p>	<p>Wristband Transmitter</p>  <p>RT26-5001E-02</p>	<p>Necklace Transmitter</p>  <p>RT27-5001E-01</p>
<p>Push-Button Transmitter</p>  <p>RT28-5001E-01</p>	<p>Hand Transmitter</p>  <p>RT24-5004E-01</p>	<p>Hand Transmitter</p>  <p>RT29-5010E-01</p>	<p>Hand Transmitter</p>  <p>RT29-5005E-01</p>	<p>Hand Transmitter</p>  <p>RT29-5004E-01</p>	<p>Multi-Channel Transmitter</p>  <p>RT22-5022E-01</p>
<p>Built-In Transmitter</p>  <p>RTS03-5004E-01</p>	<p>Radio Light Sensor</p>  <p>SL01-5001FS-01</p>	<p>Radio Wall Sensor</p>  <p>RTS05-5001E-01</p>	<p>Radio Wall Switch</p>  <p>RTS08-5002E-01</p>	<p>Radio Wall Switch</p>  <p>RTS08-5004E-01</p>	<p>Radio Wall Switch</p>  <p>RTS13-5003E-01</p>
<p>Radio Wall Switch</p>  <p>RTS13-5001E-01</p>	<p>Radio Wall Switch</p>  <p>RTS14-5006E-01</p>	<p>Radio Wall Switch</p>  <p>RTS14-5003E-01</p>	<p>Radio Wall Switch</p>  <p>RTS14-5002E-01</p>	<p>Radio-Timer</p>  <p>RTS07-5004E-01</p>	<p>Junction Box Repeater</p>  <p>RTR03-5001E-01</p>
<p>Junction Box Receiver</p>  <p>RCJ01-5001E-01</p>	<p>Junction Box Receiver/Timer</p>  <p>RCJ02-5002E-01</p>	<p>Plug-In Receiver</p>  <p>RCP05-5001E-01</p>	<p>Plug-In Receiver (pulse output)</p>  <p>RCP02-5001E-01</p>	<p>Mini Receiver</p>  <p>RCL03-5002E-01</p>	<p>Mini Receiver</p>  <p>RCL04-5002E-01</p>
<p>Universal-Receiver</p>  <p>RCU08-5002E-01</p>	<p>Plug-In Radio Bell</p>  <p>RCP04-5001E-01</p>	<p>Push-Button System 45</p>  <p>RTS09-5001E-01</p>	<p>Receiver System 45</p>  <p>RCJ03-5001E-01</p>	<p>Built-In Receiver</p>  <p>RCU10-5002E-01</p>	<p>Built-In Receiver (motor control)</p>  <p>RCU09-5001E-01</p>